

Casira RF module connections.

Connector Number	Pin Name
1	0 volts
2	+3v15 RADIO
3	0 volts
4	+3v15 P.A.
5	SPI_MISO
6	RESET_IN
7	UART_TX
8	SPI_MOSI
9	UART_RTS
10	SPI_CSB
11	PCM_OUT
12	SPI_CLK
13	PCM_CLK
14	UART_RX
15	PCM_SYNC
16	UART_CTS
17	USB+ / UART_RTS
18	PCM_IN
19	USB- / UART_CTS
20	PIO(2)
21	PIO(0)
22	PIO(3)
23	PIO(1)
24	PIO(5)
25	PIO(4)
26	PIO(6)
27	PIO(7)
28	TEST_A
29	0 volts
30	TEST_B

File E:\Casira Support info\CASI-SP-007A.doc

The information contained in this letter is intended for the named recipients only. It may contain privileged and confidential information and, if you are not an intended recipient, you must not copy, distribute, or take any action in reliance on it. If you have received this letter in error, please notify the sender immediately by reverse charge telephone call to 01223 424167 and return the original by post. We will reimburse you the postage.